

SLUSHIE MACHINE INSTRUCTIONS

- DO NOT USE AN EXTENSION CORD!
- DO NOT USE ANY ICE IN THE MACHINE!
- DO NOT USE ANY LIQUID THAT CONTAINS PULP, SEEDS, ETC.!
- DO NOT USE ONLY WATER!
- DO NOT USE KOOL-AID!
- DO NOT USE ABOVE 80 DEGREES ROOM/OUTDOORS! MACHINE MAY OVERHEAT AND NOT WORK CORRECTLY!

SUGAR CONTENT MUST BE CORRECT

TOO LITTLE SUGAR WILL RESULT IN ICE BUILD UP ON BARREL AND SEVERE DAMAGE WILL OCCUR!!

TOO MUCH SUGAR OR ALCOHOL WILL RESULT IN LACK OF FREEZING

- ☑ MACHINE **MUST** BE PLACED ON LEVEL SURFACE. YOU CAN MAKE SLIGHT ADJUSTMENTS WITH THE LEGS.
- ☑ TEMPERATURE SWITCHES MUST BE SET AS PICTURED ON BACK.
- ☑ THE BACK SIDE HAS A WHITE TURN DIAL WITH ADJUSTMENTS 1-5, THIS IS THE DENSITY DIAL. IT IS SET TO 5 (HIGH), ADJUST AS NECESSARY WITH 5-COLDEST AND 1-WARMEST TO THIS OR THICKEN MISTURE(RECOMMENDED TO LEAVE DIAL AT 5 UNTIL LIQUID IS A SLUSH)
- ☑ MUST HAVE PROPER VENTILATION AROUND THE MACHINE WHEN IN USE.
- ☑ USE CAUTION WHEN LIFTING THE MACHINE, IT IS EXTREAMLY HEAVY.
- ☑ IF YOU USE YOUR OWN SOLUTION, PARTY-N-JUMP CANNOT GUARANTEE RESULTS

RECIPE:

APPROXIMATELY 2 – 2 ½ HOURS PRIOR TO USE, ADD THE FOLLOWING:

(NON ALCOHOLIC)

FOLLOW INSTURCTIONS ON THE BACK OF THE SOLUTION GIVEN TO YOU. REPLACE ALCOHOL WITH WATER. DO NOT MIX IN THE MACHINE, USE 5 GALLON CONTAINER PROVIDED. THE MACHINE NEEDS TO BE RANDOMLY SUPERVISED AT ALL TIMES!

(WITH ALCOHOL)

FOLLOW INSTURCTION ON THE BACK OF THE SOULUTION GIVEN TO YOU BY MIXING COMPONENTS IN 5 GALLON CONTAINER PROVIDED. WITH ALCOHOL THE MIX WILL NOT REACH THE SAME SLUSH CONSISTANCY.

SLUSHIE MACHINE CLEANING:

DO NOT TAKE MACHINE APART!

FILL EACH SIDE (DBL) WITH WARM SOAPY WATER AND DISPENSE UNTILL THOROUGHLY RINSED.

WITH A SOFT CLOTH WIPE DOWN ALL SIDES INSIDE AND OUT OF THE MACHINE.

TURN OFF MACHINE IMMEDIATELY IF CLUNKING IS HEARD OR IF LARGE CHUNKS OF ICE ARE SEEN!!

If the machine is not working for you....Party-N-Jump will send out a technician at your request. If the above mentioned guidelines have not been met, a \$100.00 service charge will be added to your rental.


Leander (512) 267-5867 / Copperas Cove (254) 518-4386 Ed 512-517-2088

If a complaint is received, Party-N-Jump will test the machine with our solution. If the machine is found to be working properly, you will be charged for the rental AND the test solution!!

If there is a problem with the machine and cannot be fixed, NO refunds will be given if a call is not made during the event!

FAMILIARIZING YOURSELF WITH THE CONTROLS

On the right side of the machine are the following switches and controls. (Figure 1)



Enjoy 😊